Branch Address

+4

Select PC

New PC

Program Counter

CPU Instructions Fetch and Execute

opcode